



Move slider forward by attaching the handle bar and expose rear mounting holes of the slider

Step 1
Attach both sliders to the frame with 1x M8x12 bolt as shown.

Step 2
Bend the slider handle to the desired width*. Use the handle to move both the left and right slider backwards exposing the fastening holes in the front.

* Bend the slider handle to the desired width.

Step 3
In the backwards position, attach the left and right seat bracket as shown using a M8x16 bolt + M8 Locknut.

Step 4
Slide the slider to the front and repeat for the front-end of the seat brackets.

