

PEDAL SLIDER BASEPLATE VERSION 1.5 Last updated: 16-05-2022

BEFORE YOU START:


Thank you for purchasing this Sim-Lab product! On the following pages, you will find detailed instructions on assembly. This requires only a set of simple tools and some of your time. Please check the bill of materials before starting (page 14) and make sure all the parts are delivered.

Compatibility:


This accessory is compatible with more than one of our products. The main two ways of attaching our (seat) sliders to our cockpits are either directly on profile or on a pedal deck. This manual shows both of these options using a P1-X pedal deck (profile) and a GT1-EVO pedal deck (plate). However, compatibility of this accessory is not limited to these cockpits. Please see the product page for more information on compatibility.

Inserting Slot-Nuts:

You got excited, finished the build, put the caps on, but forgot to install one element. Do not worry. It happens to everyone. In this diagram, you can see how to insert a Slot-Nut directly into the slot from the side. You can also use one of your smaller Hex wrenches to help wiggle the Slot-Nut in place.




Tools needed:





ois needed.


4/5/6MM 8



































PEDAL BASE PLATE					
#	Part	QTY	Note		
A1	Pedal base plate	1			
A2	Bolt M8 X 16 DIN 912	4			
A3	Bolt M8 X 12 DIN 912	4			
A4	Bolt M6 X 20 DIN 912	12			
A5	Bolt M5 X 25 DIN 912	12			
A6	Bolt M8 X 20 DIN 7991	4	Countersunk		
A7	Washer M8 DIN 125-A	8			
A8	Spacer male/female M8 X 15	4			
A9	Slot-Nut M8	6			
A10	Lock-Nut M8	10			
A11	Lock-Nut M6	12			
A12	Lock-Nut M5	12			


SEAT SLIDER (optional purchase)						
#	Part	QTY	Note			
B1	Seat slider LEFT	1				
B2	Seat slider RIGHT	1				
B3	Seat slider handle	1				


HEEL REST (optional purchase)					
C1	Heel rest	1			
C2	Bolt M6 X 40 DIN 7991	4	Countersunk		
C3	Bolt M6 X 35 DIN 7991	4	Countersunk		
C4	Plastic sleeve M8 X 20	4			
C5	Plastic sleeve M8 X 10	4			
C6	Slot-Nut M6	4			
C7	Lock-Nut M6	4			
Disclaimer: for some entries on this list, we supply more than required as spare materials. Don't worry if you have some leftovers, this is intentional.					

















If you still have some questions regarding assembly of this product or about the manual itself, please refer to our support department. They can be reached at

support@sim-lab.eu

Alternatively, we now have a Discord server where there are quite some experienced Sim-Lab customers hanging out. They might just help you along if you ask them nicely ;)

www.sim-lab.eu/discord

If you feel like printing this manual, please consider the environment before doing so. For the best results, make sure you print at 100% scale without borders.



Product page on the Sim-Lab website:

Seat Slider installation on YouTube:

